aspire



Huracan EX

User Manual

EN

DISCLAIMER
Please read this user manual before use. Failure to follow the instructions in the proper setup, use and care for your device may result in damage, personal injury, fire, death, or property damage.

The manufacturer assumes no responsibility for any damage caused by misinterpreting the information in this user manual or misuse of the device.

RECOMMENDED SETUP
We recommend the exclusive use of Aspire original charger, battery, components, and accessories indicated on the product page and leaflet. Use of chargers, batteries, components, and accessories not specifically produced by the manufacturer may cause overheating, damage to the product and to the cancellation of the warranty.

HANDLING AND USAGE SAFETY
To reduce the risk of fire, shock, or damage to your vape device keep the product and its accessories away from children and animals and pets. Improper use may void the warranty.

Your device can be damaged if dropped, burned, punctured, crushed, or if it comes in contact with liquid. If you suspect damage to your device or its battery, discontinue use of your device, as it may cause overheating or injury.

To avoid irritating always ensure you either lick or switch off your device when it is not in use, especially when carrying your device in your pocket, bag, or purse.

In the case of burn or abnormal deformation of one of the components of the device or its accessories, stop using it immediately and contact Customer Care.

COIL MAINTENANCE SAFETY
In order not to damage the coil or burn the cotton do not inhale while adding e-juice. Let the cotton stand for 5 minutes after filling so the cotton can be saturated with e-liquid before use.

REPLACEABLE BATTERIES SAFETY
Do not use non-rechargeable batteries. Do not use damaged batteries or batteries with a torn or damaged wrapper. Do not disassemble, crush, or puncture the battery. Do not use your vape device while charging.

PRODUCT DISPOSAL SAFETY
Do not discard this product and battery in the environment, and only dispose of the product components at dedicated waste electronics points.

HEALTH WARNING SAFETY
Do not use the product if you are pregnant, breastfeeding, generally ill, or suffer from respiratory and/or cardiovascular system disorders.

If you experience any side effects discontinue using the product, if the effect(s) continue after you stop using consult a healthcare professional immediately.

HANDLING AND USAGE SAFETY
To reduce the risk of fire, shock, or damage to your vape device keep the product and its accessories away from children and animals and pets. Improper use may void the warranty.

Your device can be damaged if dropped, burned, punctured, crushed, or if it comes in contact with liquid. If you suspect damage to your device or its battery, discontinue use of your device, as it may cause overheating or injury.

To avoid irritating always ensure you either lick or switch off your device when it is not in use, especially when carrying your device in your pocket, bag, or purse.

In the case of burn or abnormal deformation of one of the components of the device or its accessories, stop using it immediately and contact Customer Care.

COIL MAINTENANCE SAFETY
In order not to damage the coil or burn the cotton do not inhale while adding e-juice. Let the cotton stand for 5 minutes after filling so the cotton can be saturated with e-liquid before use.

Package Contents
* 1 x Huracan EX Pod
* 1 x Aspire Tank (5.5 ml)
* 1 x BF Mesh Coil 0.15 Ω (preinstalled)
* 1 x BF Mesh Coil 0.6 Ω (preinstalled)
* 1 x Spare Build Deck Type C
* 1 x O-ring Pack
* 1 x Drip Tip
* 1 x User Manual

Components View

Kit Dimensions: 139.75*52 mm

Tank Specifications
Aspire Tank
810 Replaceable drip tip
Capacity: 5.5 ml
Top Filling System
Leak-proof design with user-friendly ergonomic
Compatible Bell Cover: Compatible with Huracan EX

Cut Installation

1. Cut off the seal on the bottom hardware with force.
2. Cut the sealed coil out with force and push the new one in firmly.
3. Screw the bottom hardware back with force.

Tank Tube Replacement
1. Remove the bottom hardware by firmly unscrewing it.
2. Hold the tank tube, place the chunky end of the new tank tube into and push it until the sealed gasket fuse with much force.
3. Push the bottom hardware back in.
4. Gently screw the bottom hardware.



Remember to clean the condensation in the tank.

Instructions

Operations	Details
Turn on / off	Long press the button for 3 seconds to turn on/off the device.
Lock or unlock the screen	Long press the button for 3 seconds to lock/unlock the screen.
Screen switching	Short press the button to switch the screen.
Before each use, check the coil	Check the coil for any damage or leakage.

Safety Features

Safety Feature	Description
Short Circuit Protection	The device will display "SHORT CIRCUIT"
Open Circuit Protection	The screen will display "OPEN CIRCUIT"
Low Resistance Protection	The device will display "LOW RESISTANCE"
Low Voltage Protection	The device will display "LOW BATTERY"
Overcharge Protection	The device will stop charging
Over-heat Protection	The screen will display "OVER HEAT"
Abnormal Charge Protection	The screen will display "CHECK USB"
Battery Reverse Protection	The device will stop working

Battery Installation

Charging

Maximum charge current	2A
Recommended Charge Voltage	5V
Internal Pure Cell	1.5Ah
Type of port	The cell will be fully charged by the Type-C port.
The charging voltage is 5V/2A, and the charging time is about 1.5 hours.	The cell will be at 100% full and ready to use.

If you press the button while charging, the battery will stop charging temporarily.

Note
The fan will display "NEW ATOMIZER" only under the 10 minutes when you first time to use the device.

Under any mode, when switching to "Puff" press "+" button, the puffs will return to the default value of 3000, and will not remember the last puffs value you set.

Under any mode, when switching to "Puff" press "-" button, the puffs will return to the default value of 3000, and will not remember the last puffs value you set.

Under any mode, when switching to "Puff" press "+" button, the puffs will return to the default value of 3000, and will not remember the last puffs value you set.

Parameters Setting
Short press "+" button.

The first menu that is the screen will display "BATTERY CAPACITY", "WATT", "WATTAGE", "VOLTAGE", "CURRENT", "OHM", "RESISTANCE", "PUFF", "PUFFS".

Long press "+" button.

Press the button and "+" button simultaneously to enter the menu operation.

Instructions

Operations	Details
Air inlet adjustment	Rotate the air inlet ring to adjust the airflow.
Spare build deck installation	Unscrew the bell "Ni", then unscrew the build deck and install a new one.
Spare coil installation	Unscrew the bell "Ni", then unscrew the old coil and install a new one.
Replacement glass	Unscrew the bell "Ni", then unscrew the glass and install a new one.
Replacement tank tube	Unscrew the bell "Ni", then unscrew the tank tube and install a new one.
Refilling the tank	Unscrew the bell "Ni", then unscrew the tank tube and refill the tank.
Cleaning the tank	Unscrew the bell "Ni", then unscrew the tank tube and clean the tank.
Cleaning the coil	Unscrew the bell "Ni", then unscrew the coil and clean the coil.
Cleaning the glass	Unscrew the bell "Ni", then unscrew the glass and clean the glass.
Cleaning the build deck	Unscrew the bell "Ni", then unscrew the build deck and clean the build deck.
Cleaning the bell	Unscrew the bell "Ni" and clean the bell.
Cleaning the bottom hardware	Unscrew the bottom hardware and clean the bottom hardware.
Cleaning the bell "Ni"	Unscrew the bell "Ni" and clean the bell "Ni".